

FRONTLINE® HEADER DISPLAY INSTALLATION INSTRUCTIONS

Unpack and Locate

- Signage
- Display
- Screw Pack

STEP 1: Place FrontLine header display on top of the door slab.

STEP 2: From backside - It is important to center the display on the door slab and to make sure your "Gap" is equal on both sides.

STEP 3: Locate two (2) screw holes on top of door jamb and use the two (2) 2" course thread screws and screw display to top edge of the door slab.

STEP 4: Locate sign and peel paper off the strip of tape down the edge of the sign.

STEP 5: Place sign so that the top edge of the sign is flush with the bottom edge of display and firmly press sign to edge of door slab.

